



# 15" FREEZER PAPER CUTTER

## Care and Use Guide



### Features:

- Durable steel construction with grey finish
- Straight, double-sided cutting edge
- Includes rubber feet to protect surfaces
- Holds up to 9" diameter roll
- Mount on countertop, under counter or on wall  
(hardware sold separately)

For your safety and continued enjoyment of this product,  
always read the instruction book carefully before using.

# IMPORTANT SAFEGUARDS

## CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.


### ***When using any product, basic safety precautions should always be followed, including the following:***

1. Read all instructions before using your product.
2. Do not clean using any abrasive materials.
3. Never force any parts or brackets into position.
4. Keep away from moving parts. Moving parts can create pinch points which may result in serious injury.
5. Make sure all product parts are assembled correctly before use.
6. Do not use any attachments that are not recommended, and don't use this product for any other purpose except its intended use.
7. This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
8. Do not use the product if it appears to be damaged.
9. Do not try to repair this product by yourself. Contact Customer Service at 1-800-288-4545.
10. Close supervision is required when this product is used near children.
11. KEEP OUT OF REACH OF CHILDREN. Children should be supervised to ensure that they do not play with this product.
12. Cleaning and user maintenance shall not be done by children without supervision.

## **SAVE THESE INSTRUCTIONS**

**THIS PRODUCT IS FOR HOUSEHOLD USE ONLY**

# LIST OF COMPONENTS



- 1. Cross Bars**
- 2. Non-Slip Feet**
- 3. Dowel Rod**
- 4. Dowel Brackets**
- 5. Cutting Blade**

## OPERATING INSTRUCTIONS

1. Grasp both crossbars (#1) and pull apart until the unit locks open.
2. To use on a counter – Install the four non-slip rubber feet (#2) onto the crossbars.
3. To use on a wall or under a counter – install with hardware.  
(Hardware not included)
4. Place one hand on the dowel rod (#3) while opening the cutting blade (#5) until it locks into place.
5. Remove the dowel rod and slide it through the freezer paper's core plugs.
6. Install the roll of material by placing the exposed ends of the dowel rod into the two dowel brackets (#4).
7. Push the spring-loaded blade down so it rests securely against the freezer paper.
8. The paper cutter is now ready to dispense.

**NOTE:** To avoid injury, use caution when positioning the spring-loaded cutting blade or loading the paper cutter with material.

IF MISSING PARTS, PLEASE CALL CUSTOMER SERVICE AT 1-800-288-4545.  
DO NOT RETURN ITEM TO STORE.



## LIMITED WARRANTY

Your product is warranted for one year from date of purchase against all defects in material and workmanship. Should your product prove defective within one year from date of purchase or receipt, return the unit, freight prepaid, along with an explanation of the claim. Please package your product carefully in its original box and packing material to avoid damage in transit. We are not responsible for any damage caused to the product in return shipment.

Under this limited warranty, we undertake to repair or replace any parts found to be defective at our sole discretion. This limited warranty is only valid if the product is used solely for household purposes in accordance with the instructions. This limited warranty is void if the unit is connected to an unsuitable electrical supply, or dismantled or interfered with in any way or damaged through misuse.

**LIMITATION OF REMEDIES AND DAMAGES:** Except for the limited warranty and remedies expressly stated above, the Metal Ware Corp shall not be liable to you, or to anyone claiming by or through you, for any obligations or liabilities, including, but not limited to, obligations or liabilities arising out of breach of contract, breach of warranty, statutory claims, negligence or other tort or any theory of strict liability, with respect to the product or the Metal Ware Corp's acts or omissions or otherwise. Buyer agrees that in no event shall the Metal Ware Corp be liable for incidental, compensatory, punitive, consequential, indirect, special or other damages. Warranty does not cover consequential or incidental damages such as property damage and does not cover incidental costs and expenses resulting from any breach of this warranty, even if foreseeable. Some states or provinces do not allow the exclusion or limitations of incidental or consequential damages, so the above limitation or exclusion may not apply to you depending on the State or Province of purchase.

We ask that you kindly fill in the details on your warranty card and return it within one week from date of purchase.

Send warranty card to:

Chard PPR-CTR / Freezer Paper Cutter  
C/O MW  
P.O. Box 237  
Two Rivers, WI 54241

©2018 Metal Ware Corp, P.O. Box 237, Two Rivers, WI 54241 1-800-288-4545